


Manual No. 9214


10/26

INSTALLATION

1-point lock



**Residential garage door
RE100-RT200**




IMPORTANT!

**To be installed
to the preparation
of intermediate
panel no. 1**

(Document reserved for installers)


Preparation of intermediate panel no. 1

Mounting exterior/interior facade




Left interior view


Right interior view



Position of the outer handle
Functional variant




Door unlocked




Door locked

OR







Position of the outer handle
Aesthetic variant




Door unlocked






Door locked

Mounting the latch (length 190 mm) and his guide (Door off-cassette)**Mounting the latch (length 510 mm) and his guide (cassette door)**

Operate the handle until full release
of the lock shaft




If $X + 60 \text{ mm} < 450 \text{ mm}$,
then the latch must be cut back


Cutting the latch:

Door finish (after adjusting the balancing)

Drilling into the guide rail



Operate the handle until it touches the guide rail



Trace the point of the latch

