



Connection of the road tube

with the PIC 4410, Intellidrive 400 or CS 300/310 boxes

PULSE OR AUTOMATIC OPERATION

Connection with a PIC 4410 box






6465



Connection with a CS 300/310 box



Before connecting the Road tube, ensure that all of the instructions in the connection manual for the PIC 4410, Intellidrive 400 or CS 300/310 boxes have been followed.
Ensure the box is well sealed in relation to the wall support using a flexible sealant.