

PACKAGING MANUAL

N°7392

09/15

Fencing elements



(Document reserved for installers)

Contents

Presentation of the different packaging elements :

- Overview	p.3
- U-shaped protective foam	p.3
- Polystyrene	p.4
- Angle foam	p.4
- Shrink film	p.4

Packaging a fencing element module :

- Necessary elements (for a fencing element)	p.5
- High and low transom	p.5
- Corner protection	p.6
- Protection of columns	p.6
- Positioning polystyrenes	p.7


Covering with heat-shrink wrap	p.7
---	------------

Presentation of the different packaging elements

1 - Overview :



2 - U-shaped protective foam :




U 45x60
mainly for transoms

U 80x60
for lock columns
(or central columns)
and for sliding transoms

U 45x70
for post columns

3 - Polystyrene :



Section : 80x50mm, length 1.20M.

4 - Corner foam :



5 - Shrink wrap :




7M for Fencing elements.

Packaging a Fencing element module

1 - Elements necessary (for a Fencing element) :




Shrink wrap (7M)




Polystyrenes (x12)



U-foam 45x60 (x2)




U-foam 70x45 (x2)



Corner foam (x4)

2 - High and low transoms :



The foam is placed directly on the transoms and covers all the transom, from one column to the other.

3 - Corner protection :




Each corner covers the top and bottom of each column as well as the protective foam of the transoms.
Protect the 4 corners.

4 - Protection of columns :



The foam is placed directly on the column, but must not cover the foam corners.

5 - Positioning the polystyrenes :



Place the 3 polystyrenes flat on the inside and tape them down.
Place the other 3 polystyrenes flat on the outside and tape them down.

Covering with heat-shrink wrap



Tape it back to the shrink wrap to ensure it stays in place.

Otherwise, if you have the right material, it is preferable to heat-seal the film in order to stretch it.

If you use this type of material, do not tape.

Example of adapted material : **Gas retraction kit.**



Gas retraction kit

If the foams and polystyrenes have been correctly positioned, the plastic film will not stick to the gate under the effect of heat.

Result :

